

JICK START

# GUIDE Welcome to

CITYPLAY powered by Playermaker! Follow the instructions in this guide to learn how to charge your sensors, conduct an activity, sync your data onto the app and more!

### Use the provided cable to charge your sensors before every activity

**IGHTS STATUS** 

HARGING SENSORS AND

- Charge your sensors by plugging the charging cable into the bottom of the case and into a
- When your sensors are charging, status lights will shine and display the relevant battery state
- **Green lights**



power outlet

### You have up to two hours of recording

time

**Orange lights** 

Low level battery -

You are ready to play

**Red lights** 

Cannot start an

activity - Sensors

require charging



#### When your sensors are not charging, status lights will shut off and your sensors

**Important:** The case charges the sensors only when connected to a power outlet

Download the "CITY.PLAY" app from

Download on the

**App Store** 

Create your profile

Pair your sensors

from the case

Start playing!

sensors correctly

the straps on your boots



2 SIGN UP



Download from the

Android app


## THE PITCH!

your session is actively being recorded Insert your sensors into the straps and place

Your sensor lights will blink blue indicating

Start your session by removing your sensors

Watch the video to learn how to strap the



To sync your data, make sure your bluetooth is on and your sensors are nearby. Open the app

and follow the on-screen instructions to

**Important:** Keep your sensors inside their case when you are not recording an activity

Your data

is almost here

Syncing activity...

explore your performance.



 Don't take the sensors out of the kit during the syncing. For more information, contact support www.playermaker.com/cityplay